

### 4-AXIS Motion

FUNC	PIN#	PIN#	FUNC
GND	1	2	
STEP_1	3	4	
DIR_1	5	6	
HOM_1	7	8	GND
FWD_1	9	10	
REV_1	11	12	
INPUT_1	13	14	GND
STEP_2	15	16	GND
DIR_2	17	18	GND
HOM_2	19	20	GND
FWD_2	21	22	
REV_2	23	24	GND
INPUT_2	25	26	GND
STEP_3	27	28	GND
DIR_3	29	30	GND
HOM_3	31	32	
FWD_3	33	34	GND
REV_3	35	36	
INPUT_3	37	38	GND
STEP_4	39	40	GND
DIR_4	41	42	
HOM_4	43	44	
FWD_4	45	46	GND
REV_4	47	48	
INPUT_4	49	50	GND